



Indicator specification

LED	STATE	COMMENT
1	ON	5V USB voltage applied
	OFF	No 5V USB voltage applied
2	ON	Battery charge
	OFF	Battery charged/no 5V
3	BLINKING	Typical on mode
	BLINKING FAST	Wireless module configuration mode
	OFF	Controller standby
4	ON	Wireless datalink
	OFF	No wireless datalink

Controller modes

Mode	How to enter	LED INDICATION
Standby	Press left joystick once	LED3 OFF
Typical on mode	Press left joystick once	LED3 BLINKING
Wireless module config	Press and hold left joystick for 5 seconds	LED3 BLINKING FAST